

MAIN MENU OPTIONS:

- ▼ Press 1 to retrieve messages.
- ▼ Press 3 to send messages.
- ▼ Press 5 to check all sub mailboxes.
- ▼ Press 7 for current date and time.
- ▼ Press 9 for mailbox setup.

LISTEN TO MESSAGE OPTIONS:

- ▼ Press 1 to play messages.
- ▼ Press 2 to save messages.
- ▼ Press 3 to delete messages.
- ▼ Press * to return to the main menu.

TO SET UP YOUR MAILBOX PASSWORD FROM YOUR TELEPHONE:

1. Dial *98 then the * key.
2. Enter password then the # key.
3. Set-up group greeting.
4. Press 4 then the # key.
5. Press 2 to save group greeting.

TO CHECK MESSAGES AT HOME:

1. Dial *98.
2. Press 1 or the mailbox number.
3. Follow voice prompts.
4. Press 5 to check all sub mailboxes.

TO CHECK MESSAGES AWAY FROM HOME:

1. Dial *98 if (in local serving area) or 270-665-5222 (outside serving area).
2. Enter mailbox number.
3. Enter password and # key.
4. Follow voice prompts.